



VOORZETHOR

VOOR NAAR BINNEN DRAAIENDE RAMEN

Handleiding

Guide d'installation

Manual

FENÊTRE MOUSTIQUAIRE





POUR FENÊTRES S'OUVRANT VERS L'INTÉRIEUR

SCREEN WINDOW


FOR WINDOWS TURNING INSIDE

STD

TOOLS



⊕
Ph 2



M4x20mm **A**
(2x)





M4x16mm **B**
(4x)




(4x) **C**




M4x8mm **D**
(4x)



16,4x6mm **F**
(4x)




26,4x 9mm **G**
(4x)




28,4x9mm **H**
(4x)



M4 **E**
(10x)



J




1




2

3


4

5







4




5




6




7




8




9 | OPTION 1




9 | OPTION 2



9 | OPTION 3



10



11

